

Betriebsanleitung Gepäckspanner

Art. Nr. 194-45, 194-60, 194-80, 194-100, 194-8



**Vor Inbetriebnahme unbedingt die Betriebsanleitung lesen!
Betriebsanleitung aufbewahren und dem Anwender zum Lesen zur Verfügung stellen!**

Sicherheitshinweise

- Nicht über scharfe Ecken und Kanten führen.
- Darf nicht zum Heben von Lasten verwendet werden!
- Bei Beschädigung nicht verwenden!
- Bei Überbeanspruchung des Bandes kann dieses reißen und gefährlich zurückschlagen!
- Großflächige Teile gegen Windlast zusätzlich sichern!
- Achtung! Spannband nicht als Ladungssicherung verwenden!
- Nicht über die zulässige Zugkraft dehnen.
- Darauf achten, dass die Befestigungspunkte für die Haken des Gepäckspanners stabil genug sind.
- Den Gepäckspanner nur mittels der Haken (auf keinen Fall durch verknoteten des Gummibandes oder ähnliches) befestigen.



**Gepäckspanner können zurückschnellen und schwere Verletzungen verursachen!
Besonders auf den Schutz des Kopfes und wichtiger Körperteile achten.**

Bestimmungsgemäße Verwendung

Der Gepäckspanner dient vorwiegend zum Fixieren von leichten Teilen. Er ist nicht zum alleinigen Befestigen und Sichern von Lasten an Fahrzeugen bestimmt.

Technische Daten

Art.Nr.	194-45	194-60	194-80	194-100	194-8
Model	AH-905	AH-905	AH-905	AH-905	AH-905
Länge	45 cm	60 cm	80 cm	100 cm	45 bis 100 cm
Durchmesser Gummiband	8 mm	8 mm	8 mm	8 mm	8 mm
max. zulässige Zugkraft Fzul	80 N	80 N	80 N	80 N	80 N
max. Gesamtlänge bei Fzul	74 cm	101 cm	139 cm	176,5 cm	74 bis 176,5 cm

Lagerung und Entsorgung

An einem trockenen und kühlen Ort lagern. Vor übermäßiger Hitze, Kälte und UV-Strahlung schützen. Entsorgen Sie die Verpackung und Gepäckspanner gemäß den gesetzlichen Bestimmungen.

Operating instructions elastic luggage straps

Item No. 194-45, 194-60, 194-80, 194-100, 194-8



Be sure to read these operating instructions before using for the first time.
Keep the operating instructions and give them to the user to read

Safety instructions

- Not to be pulled across sharp corners or edges.
- Not to be used for lifting loads.
- Discontinue use in the event of damage or visible external wear.
- With overloading the luggage strap it can tear apart and snap back dangerously.
- Large parts should be additionally secured against wind load!
- Caution! Do not use luggage strap for load securing.
- Do not stretch the elastic luggage strap beyond the permissible tensile force.
- Ensure that the attachment points for the hooks of the elastic luggage strap are stable enough.
- Attach the elastic luggage strap using the hooks only (never by knotting the elasticated strap or similar methods).



Elastic luggage straps can snap back and cause severe injuries! Pay special attention to protecting the head and vital body parts.

Intended use

The elastic luggage strap is intended for the fixing of lightweight objects (e.g. in the luggage compartment). Not to be used as the sole means of fixing and securing loads on vehicles

Technical data

Item No.	194-45	194-60	194-80	194-100	194-8
Model	AH-905	AH-905	AH-905	AH-905	AH-905
Length	45 cm	60 cm	80 cm	100 cm	45 bis 100 cm
Diameter of elastic strap	8 mm	8 mm	8 mm	8 mm	8 mm
permissible tensile force Fzul	80 N	80 N	80 N	80 N	80 N
max. total length with Fzul	74 cm	101 cm	139 cm	176,5 cm	74 bis 176,5 cm

Storage and disposal

Store in dry and cold locations. Keep away from too much heat, cold and UV-radiation.

Dispose all material acc. national regulations.